



- **Anchor Load** - If the offshore structure is temporary or mobile then anchor points will be used to secure its position. The forces on these require to be measured. We provide load pins or running line tensionmeter measurements for this application.

